

Counter flashing extends up under the skylight flashing and back into the shingle locks.

Base flashing extends up under the skylight flashing, on top of the sidewall flashing, and back under the underlayment.

Extend the sidewall flashing at least 4" past the back of the skylight.

4001 Great American Shake

Shingles cut to fit around the skylight.

421 Sidewall flashing

4009 Nailing clip

Note: Some shingles and accessories are not shown to reveal flashing details.

Skylight

Extend the sidewall flashing at least 2" past the front of the skylight and past the shingle toplock. This lap will vary depending on how the shingle courses land.

Extend the front flashing up under the skylight flashing and at least 4" onto the lower shingle.

Drawn By: Eric Voress	Isaiah Industries, Inc.
Date: 4/5/2023	Part Name: Great American Shake skylight assembly
Scale: 1:12	Part Number: